

# Using the TV in Room 105

## Switch from Computer Mode to TV Mode

By: Kenneth L. Jones

Date: 10-8-2018

It can be difficult with three remotes to know how to control the TV and Computer. You can either watch TV or play a YouTube Video on the Computer. If you would like to watch TV and the previous user has it set up for the computer, you must locate the remote control for the TV. Use the **Input** button in the **upper left** hand corner of the remote to change inputs.

Press the input button and the TV screen will show a list of available inputs. On the screen shown below the **currently selected input is HDMI-2 or Computer**. By pressing the input button again, you can select the next input. On the list below you can see the label **12-1 WTLV-HD**. Press input until 12-1 is selected. This will switch the TV input to Antenna. You can then use the channel up and down buttons to scan the available channels. When you are done with the TV press the power button to turn it off.



Visio  
TV Remote



Yamaha  
Stereo Remote

### Input

HDMI 1

HDMI 2

COMP

Channel + Call Letters

### Connected Device

Yamaha Stereo with Sony DVD Player

Computer

Nothing

TV HD Antenna